

1	Mounting Bracket	RM BRACKET
2	Filter Assembly	FA S28
3	Push Lock Fitting	PL PLA 04
4	Check Valve	BR PA6
5	Safety Relief Valve	BR SV-25-50
6	Bulkhead	PL PLB 02X04
7	Power Cord	EL CORD115V-RM
8	Pressure Switch S163R (30-40 PSI) S253R (23-28 PSI) S481R (13-18 PSI)	EL Q976 EL Q979 EL Q975
9	Filter Assembly	FA S28

